



Nortel CallPilot

Desktop Messaging User Guide for My CallPilot

ATTENTION

Clicking on a PDF hyperlink takes you to the appropriate page. If necessary, scroll up or down the page to see the beginning of the referenced section.

Document status: Standard
Document version: 01.01
Document date: 26 February 2007

Copyright © 2007, Nortel Networks
All Rights Reserved.

Sourced in Canada

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

The process of transmitting data and call messaging between CallPilot and its servers, switches or system is proprietary to Nortel Networks. Any other use of the data and the transmission process is a violation of the user license unless specifically authorized in writing by Nortel Networks prior to such use. Violations of the license by alternative usage of any portion of this process or the related hardware constitutes grounds for an immediate termination of the license and Nortel Networks reserves the right to seek all allowable remedies for such breach.

Nortel Networks and third-party trademarks appear on the following pages:

*Nortel, the Nortel logo, the Globemark, and Unified Networks, BNR, CallPilot, DMS, DMS-100, DMS-250, DMS-MTX, DMS-SCP, DPN, Dualmode, Helmsman, IVR, MAP, Meridian, Meridian 1, Meridian Link, Meridian Mail, Norstar, SL-1, SL-100, Succession, Supernode, Symposium, Telesis, and Unity are trademarks of Nortel Networks.

3COM is a trademark of 3Com Corporation.

ACCENT is a trademark of Accent Software International Ltd.

ADOBE is a trademark of Adobe Systems Incorporated.

AMDEK is a trademark of Amdek Corporation.

AT&T is a trademark of American Telephone and Telegraph Corporation.

ATLAS is a trademark of Quantum Corporation.

ATRIA is a trademark of Pure Atria Corporation.

BLACKBERRY is a trademark of Research in Motion Limited.

CASEWARE is a trademark of Caseware International, Inc.

CONTINUUS is a trademark of Continuus Software Corporation.

CRYSTAL REPORTS is a trademark of Seagate Software Inc.

DEFINITY is a trademark of Avaya Inc.

DIALOGIC, INTEL and VOICEBRIDGE are trademarks of Intel Corporation.

DIVX is a trademark of DivXNetworks, Inc.

EUDORA and QUALCOMM are trademarks of Qualcomm, Inc.

eTrust and InoculateIT are trademarks of Computer Associates Think Inc.

DIRECTX, EXCHANGE.NET, FRONTPAGE, INTERNET EXPLORER, LINKEXCHANGE, MICROSOFT, MICROSOFT EXCHANGE SERVER, MS-DOS, NETMEETING, OUTLOOK, POWERPOINT, VISUAL STUDIO, WINDOWS, WINDOWS MEDIA, and WINDOWS NT are trademarks of Microsoft Corporation.

GROUPWISE and NOVELL are trademarks of Novell Inc.

HITACHI is a trademark of Hitachi Limited.

LOGITECH is a trademark of Logitech, Inc.

LUCENT is a trademark of Lucent Technologies, Inc.

MATRA is a trademark of Matra Hachette.

McAFFEE and NETSHIELD are trademarks of McAfee Associates, Inc.

MYLEX is a trademark of Mylex Corporation.

NET2PHONE is a trademark of Net2Phone, Inc.

NETOPIA is a trademark of Netopia, Inc.

NETSCAPE COMMUNICATOR is a trademark of Netscape Communications Corporation.

NOTES is a trademark of Lotus Development Corporation.

NORTON ANTIVIRUS and PCANYWHERE are trademarks of Symantec Corporation.

POWERQUEST is a trademark of PowerQuest Corporation.

PROMARK and RHOBOT are trademarks of DMI Promark, Inc.

QUICKTIME is a trademark of Apple Computer, Inc.

RADISYS is a trademark of Radisys Corporation.

ROLM is a trademark of Siemens ROLM Communications Inc.

SLR4, SLR5, and TANDBERG are trademarks of Tandberg Data ASA.

SONY is a trademark of Sony Corporation.

SYBASE is a trademark of Sybase, Inc.

TEAC is a trademark of TEAC Corporation.

UNIX is a trademark of X/Open Company Limited.

US ROBOTICS, the US ROBOTICS logo, and SPORTSTER are trademarks of US Robotics.

WINAMP is a trademark of Nullsoft, Inc.

WINRUNNER is a trademark of Mercury Interactive Corporation.

WINZIP is a trademark of Nico Mark Computing, Inc.

Contents

How to get help	7
Using My CallPilot	9
Getting started	10
Logging on	12
Accessing your CallPilot messages	16
Playing voice messages	17
Viewing fax messages	19
Composing voice messages	20
Composing fax and text messages	23
Calling the sender of a message	25
Forwarding and replying to messages	26
Adding attachments to messages	27
Setting message options	28
Addressing messages	29
Using the Message Waiting Indicator	32
CallPilot Features tab	34
Working with greetings	34
Setting up message notification	37
Setting up message forwarding	39
Managing personal distribution lists	42
Changing your CallPilot password	43
Changing your telephone options	44
Setting up telephone access to e-mail	46
Changing fax printing options	47
Setting up links to your e-mail accounts	48
Setting messaging preferences	53
Choosing a home page for My CallPilot	54
Useful Information tab	54
Transcribing voice forms	55
Protecting the security of your mailbox	56
Appendix A Remote Text Notification for Microsoft Outlook and BlackBerry Devices	57

How to get help

This section explains how to get help for Nortel products and services.

Getting help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

<http://www.nortel.com/support>

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, you can use the site to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting help over the phone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

<http://www.nortel.com/callus>

Getting help from a specialist by using an Express Routing Code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

<http://www.nortel.com/erc>

Getting help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Using My CallPilot

My CallPilot* from Nortel is a Web-based messaging system that offers exceptional flexibility for managing your messaging needs.

You can work with My CallPilot from any computer that has network access and a Web browser configured for My CallPilot. Here are some of the many ways you can use My CallPilot:

- Record, edit, and delete greetings that callers hear when they reach your mailbox.
- Receive, forward, reply to, and send voice messages, faxes, and e-mails.
- Address messages to CallPilot users on local and remote servers, as well as to non-CallPilot users.
- Set up message forwarding to another CallPilot mailbox or to an external e-mail address.
- Configure e-mail-by-phone.
- Set up links to your e-mail.
- Change your CallPilot mailbox password.
- Create personal distribution lists.
- Set up remote notification to a telephone or pager.
- Set up text message notification for a wireless e-mail device. See Appendix A for details.
- Transcribe voice forms, if your site uses voice forms to collect information.

Some features mentioned in this guide are optional. For details, refer to the *Feature availability* topic in the CallPilot Player online Help, or ask your administrator.

Note: The screen images of dialog boxes shown in this guide are those displayed when operating My CallPilot in the Windows environment, unless otherwise specified. Users of the Macintosh or

Linux environments might see altered versions of these dialog boxes, depending on specific feature and functionality support.

Getting started

About this guide

This user guide describes how to use the Web-based resources of My CallPilot. The instructions and screen images shown in this guide provide general information for using My CallPilot through a Web client. Specific details can vary, depending on your computer operating system and the features available for your CallPilot mailbox.

Hardware and software requirements

You can access My CallPilot from any computer with network access and a Web browser configured for My CallPilot. Before you start to use My CallPilot, ensure that the computer you are using is set up according to the following requirements.

Note: Support for additional hardware and software may be added in the future as it becomes available (for example, new browser releases). For more information, contact your CallPilot administrator.

Windows-based hardware and software

- Operating systems: Windows 2000 Professional, Windows XP Professional, or Windows Vista
- Browsers: Internet Explorer 6.0 and 7.0, Firefox 2.0 for Windows
- TCP/IP network connection of at least 56 Kbit/s
- Sound card and speakers for playing voice messages on your computer
- A microphone connected to your computer, or a telephone situated near your computer, for recording voice messages

Macintosh-based hardware and software

- PowerPC G3 processor or newer (PowerPC G4 preferred)
- Operating system: Mac OS X v10.3
- Browser: Safari 1.3.2
- TCP/IP network connection of at least 56 Kbit/s
- Speakers for playing voice messages on your computer
- A microphone connected to your computer, or a telephone situated near your computer, for recording voice messages

Note: The type of microphone to use depends on the type of Macintosh you have; a microphone designed for a Windows-based PC does not always work.

Linux-based software

- Red Hat Linux 9
- Browsers: Mozilla 1.7.x, Firefox 2.0
- TCP/IP network connection of at least 56 Kbit/s
- A microphone connected to your computer, or a telephone situated near your computer, for recording voice messages

Peripheral hardware and software (including audio player)

- Video display and monitor with 8-bit (256-color) 800 x 600 capability (1024 x 768 16-bit color preferred)
- A network connection to the My CallPilot server, and to the CallPilot server where applicable, for accessing CallPilot messages
- To create faxes:
 - For Windows systems, the Nortel Fax Driver and CallPilot desktop messaging.
 - For Macintosh and Linux systems, you must provide your own software for creating faxes.
- To play and record voice messages: CallPilot Player, or another audio player that can play WAV files.
 - For Windows systems: If you are using Internet Explorer, you can use the CallPilot Player that is conveniently embedded inside the browser to play and record voice messages. Otherwise, you can use the CallPilot Player as a browser helper application (stand-alone version of the CallPilot Player). If you choose not to use the CallPilot Player, you can use the Microsoft Windows Media Player, or another WAV-compatible media player. These players do not function in exactly the same way as the CallPilot Player described in this guide.
 - For Macintosh and Linux systems, you must provide your own audio player to play and record voice messages.

Requirements for the embedded CallPilot Player

For Windows systems, My CallPilot includes an embedded audio player that conveniently appears on the page you use to compose and listen to voice messages, as shown here:



For the embedded player to automatically appear in My CallPilot, your workstation and My CallPilot must meet the following requirements:

- your browser must be Internet Explorer
- the CallPilot Player must be installed (for instructions, see ["To download audio players" \(page 15\)](#))
- you must have VBK set as your audio type in your My CallPilot preferences (for instructions, see ["Setting messaging preferences" \(page 53\)](#))

Logging on

Your administrator provides you with the URL for My CallPilot. Bookmark this address in your Web browser for easy access.

To log on to My CallPilot

Step	Action
1	In your Web browser, navigate to the My CallPilot address. Example: http://serverABC/mycallpilot
2	On the Welcome page, in the Mailbox box, type your mailbox number. This number is usually your office telephone extension number.

- 3 In the **Password** box, type the password for this mailbox.
- 4 Click **Login**.

Do not check the Remember Password box on a shared computer.

The Enable Secure Login link appears if SSL encryption is enabled.

—End—

Logging on to environments with multiple CallPilot servers

If your site has more than one CallPilot server to which you can connect, a Location list containing multiple CallPilot servers appears in the Welcome page.

Selecting a server from this list lets you select (and log on to) your CallPilot server without needing to know any of your server-specific settings beyond your mailbox and password.


To configure or update the settings to connect to My CallPilot

Under normal circumstances, your CallPilot administrator configures the settings that allow you to log on to My CallPilot. If this is not the case, you might need to add or update the settings so that you can log on successfully.

Step	Action
------	--------

- | | |
|---|---|
| 1 | In your Web browser, navigate to the My CallPilot address. |
| 2 | On the Welcome page, click Configure .

The Configure dialog box appears. The information shown in the following illustration is an example only. |



- | | |
|---|---|
| 3 | Type or update the configuration information. If you do not have this information, contact your CallPilot administrator. |
| 4 | Click OK .

The system attempts to connect you using the information you entered. |
| 5 | If the connection is successful, click OK on the confirmation messages, and then try logging on again. If the connection is not successful, contact your CallPilot administrator for assistance. |

—End—

To change to another server

If you have a mailbox on another CallPilot server, you can log on to that server from My CallPilot. Click **Configure**, type the server details, then click **OK** until you return to the Welcome page. When you log on again from the same computer, CallPilot accesses the new server. To change back to your default server, click **Configure**, then click **Restore Defaults**.

To change to another language

If language buttons are available on your My CallPilot log on page, you can click one to change from your default language to another language.

To log on using secure login

If the Enable Secure Login link is available on your login page, click it to enable SSL encryption. The Login Securely button appears. Bookmark the link for future use.

To log on remotely

You can log on to My CallPilot from any computer that has Internet access and supported browser configuration. You can use the pre-installed audio player for voice messages, or you can download the CallPilot Player for full feature capability.

To log out

To log out from My CallPilot, click **Logout** on any My CallPilot page.

To download audio players

You need an audio player to play and record voice messages. If you do not have the CallPilot Player installed, the first time you log on to My CallPilot, you are prompted to download it. Follow the instructions to start the download and installation process. If you choose to use a different audio player, arrange to install it if it is not already installed.

If you choose not to download the player when you first log on, you can do so later on using the following procedure.

Step	Action
1	Log on to My CallPilot.
2	Click the CallPilot Features tab, and then click the Downloads item.
3	Select CallPilot Player & MWI icon or another audio player from the list.
4	Follow the instructions to download and install the audio player.
	The stand-alone version of the CallPilot Player is shown here:



—End—

Note: The CallPilot Player software is bundled with software for a Message Waiting Indicator (MWI). When installed, the Message Waiting Indicator appears as an icon in the Windows taskbar, and it notifies you when you have new CallPilot messages. For more information, see ["Using the Message Waiting Indicator" \(page 32\)](#).

Accessing your CallPilot messages

You can access your CallPilot messages from the CallPilot Messages tab. You can play voice messages and view faxes, delete, forward, and reply to messages, and compose new messages.



Your message list

To check for new messages

To see new messages, click **Refresh**. New messages appear in bold.

To sort your messages, click on a column heading, for example, **Subject** or **Received**.

Note: Only the messages currently displayed are sorted, which might not be the entire message list.

To open a message

To open a CallPilot message, click the voice, fax, or text icon in the attachments column beside the message, or click any underlined part of the message line. See ["Playing voice messages" \(page 17\)](#), and ["Viewing fax messages" \(page 19\)](#).

To select a message

To select a CallPilot message, check the box at the far left of the message line. When a message is selected, you can delete, forward, or reply to it.

To delete a message

To delete a CallPilot message, select the message and click **Delete** or **Delete Now**. If you click **Delete**, the message temporarily moves to your Deletable Items folder, and then it is permanently deleted when you log out. If you click **Delete Now**, all selected messages, and items in your Deletable Items folder, are permanently deleted immediately.

If you want to keep items in your Deletable Items folder after you log out, you can change this setting on the My CallPilot Preferences page. See ["To change environment settings" \(page 54\)](#).

Note: To view items in your Deletable Items folder, from the CallPilot Messages tab, select Deletable Items from the Folder list.

To select your telephone or computer to play and record voice messages

You can choose to play and record voice messages through your telephone or your computer. Click the telephone or computer icon in the embedded or downloaded CallPilot Player. If you have any problems using your telephone for this purpose, contact your CallPilot administrator.

See ["Setting messaging preferences" \(page 53\)](#), to change the audio setting and the number that CallPilot dials for playing and recording messages.

Playing voice messages

Before playing voice messages, see ["To select your telephone or computer to play and record voice messages" \(page 17\)](#).


To play a voice message the quick way (Windows only)

Use the embedded CallPilot Player, if available, to play your voice messages quickly. If you cannot see the embedded player in your message list, see ["Requirements for the embedded CallPilot Player" \(page 11\)](#).

Step	Action
------	--------

- | | |
|---|--|
| 1 | In your message list, click the voice icon in the attachments column beside the message you want to play (see the following illustration). |
|---|--|

Note that this icon appears as a telephone instead of a black arrow if your audio format is set to WAV in your My CallPilot preferences.




- | | |
|---|--|
| 2 | If you are not using the embedded player, follow the prompts to open the audio file. When the audio player appears, press the play button. |
|---|--|

The controls on the embedded CallPilot player are shown here:

Embedded Windows CallPilot Player

Controls on other audio players vary




If you select the computer for playback, the audio player plays your message from your computer speakers. If you select the telephone for playback, your telephone rings and plays the message when you answer.

- | | |
|---|---|
| 3 | Use the player buttons to stop or replay the message, or to call the sender. You can use the slider control on the player to skip to another part of the message. |
| 4 | If you are using the telephone, when finished, click the disconnect icon or hang up the telephone. |
| 5 | To return to your messages, click Message List . |

—End—

To play a voice message in a mixed voice, fax, or text message

CallPilot messages can have more than one type of attachment. In your message list, each attachment appears as a different icon beside the message in the attachment column.

Step	Action
1	<p>In your message list, click any underlined part of the message to open it.</p> <p>The mixed message appears with each attachment shown on the left.</p> 
2	<p>To play the voice message, click the Voice icon. For more details on playing a voice message, see the preceding procedure.</p>
—End—	

Viewing fax messages

To view faxes on your computer you must have appropriate software.

- For Windows systems, you can use the viewer included with the Windows operating system, or install your own software.
- For Macintosh systems, QuickTime Viewer can display faxes.
- For Linux systems, Eye of GNOME or kfax software can display faxes.

To view a fax message

Step	Action
1	<p>In your message list, click the fax icon in the attachments column beside the fax message you want to view, or click any underlined part of the message.</p> <p>If the Open/Save dialog box appears, select Open to display the image.</p>
2	<p>Use the controls supplied with the fax viewing software to work with the fax.</p>

- 3 When you finish, close the fax image to return to your messages.

—End—

Composing voice messages

If you use Internet Explorer for Windows, you can compose a voice message using one of two methods:

- You can use the embedded CallPilot Player to record the voice message (VBK format only) and automatically attach it to the message. If you cannot see the embedded player when you compose a message, see ["Requirements for the embedded CallPilot Player" \(page 11\)](#).
- You can use the stand-alone CallPilot Player to record your message and then save it as a stand-alone file. You can then attach it to one or more messages and send it.

These procedures are described in the following sections.

If you are using a different browser or player, or if you are using a Macintosh or Linux system, you must first record the message in your audio player and then attach it to the CallPilot message before sending it. For information about adding an attachment to a message, see ["Adding attachments to messages" \(page 27\)](#).

Note: You cannot add additional audio to audio files that exist in your inbox.

To record and send a new voice message using the embedded CallPilot Player

Step	Action
1	In your message list, click Compose . A new message page appears.
2	Address the message. For more information, see "Addressing messages" (page 29) .
3	In the Subject box, type a subject for the message.
4	Choose how you want to record the voice message: in the embedded Windows CallPilot Player, select either the telephone or the computer icon.



Note: If you select the telephone to record the message, ensure you have your telephone number configured in My CallPilot. To check, click the **My CallPilot Features** tab, and then click the **My CallPilot Preferences** item. In the **Environment Settings**, ensure your telephone number is entered in the **Number to call for telset playback (ie. your phone)** box.

- 5 To begin recording your message, click the record button.
- 6 Do one of the following:
 - If you are recording from a computer, speak into the microphone.
 - If you are recording from a telephone, answer when the telephone rings. At the tone, record your message into the handset.
- 7 When you finish speaking:
 - To end the recording, click the stop button.
 - To review the recording, click the play button.
 - To add to the recording, click the record button, speak again, and then click the stop button.
- 8 If you are using the telephone, when finished, click the disconnect icon or hang up the telephone.


- 9 When you are satisfied with the message, click **Save Audio**. This automatically adds the recording as an attachment to the message.
- 10 Click **Send**.

—End—

To record and save a message using the stand-alone CallPilot Player

To save a copy of your voice recording as a stand-alone file you must use the stand-alone CallPilot Player, not the embedded CallPilot Player.

- | Step | Action |
|------|---|
| 1 | Open the stand-alone CallPilot Player (from the Windows Start menu, choose Programs > Nortel > CallPilot Desktop Messaging > Audio Player). |
| 2 | Choose how you want to record the voice message: in CallPilot Player, select either the telephone or the computer icon. |



Note: If you select the telephone to record the message, ensure you have your telephone number configured in My CallPilot. To check, click the **My CallPilot Features** tab, and then click the **My CallPilot Preferences** item. In the **Environment Settings**, ensure your telephone number is entered in the **Number to call for telset playback (ie. your phone)** box.

- 3 To begin recording your message, click the record button.
- 4 Do one of the following:
 - If you are recording from a computer, speak into the microphone.
 - If you are recording from a telephone, answer when the telephone rings. At the tone, record your message into the handset.
- 5 When you finish speaking:

- To end the recording, click the stop button.
 - To review the recording, click the play button.
 - To add to the recording, click the record button, speak again, and then click the stop button.
- 6 If you are using the telephone, when finished, click the disconnect icon or hang up the telephone.
 - 7 On the CallPilot Player **File** menu, click **Save** or **Save As**.
 - 8 In the **File name** box, type a name for the file, select a folder to keep the file in, and then click **Save**. Save voice files as VBK files.
Note: My CallPilot automatically converts VBK files to WAV files when sending to non-CallPilot users.
 - 9 Add the saved recording as an attachment to one or more CallPilot messages. For instructions, see ["Adding attachments to messages" \(page 27\)](#).

—End—

Composing fax and text messages


To create a fax file, your CallPilot mailbox must have fax capability, and your computer must have desktop messaging installed. After you save the fax file, you can add the fax to a message as an attachment. Your CallPilot recipients must have fax capability to view your fax on their computer. If your recipients access their messages from their telephone, they can view the fax only by printing it. You can also send your fax to a fax machine.

For Macintosh and Linux systems, Nortel does not supply software for creating faxes. You must supply your own software to do this, and then attach the fax message to a CallPilot message before sending it. The fax file must be TIF-F format. For information about adding an attachment to a message, see ["Adding attachments to messages" \(page 27\)](#).

To create and save a fax file

Step	Action
1	Start the application you want to use to compose the fax, for example, Microsoft Word. The document you open or create must be 8.5 in. (21.5 cm) wide or less. Multiple page documents are allowed.
2	When the document is ready, from the File menu, click Print or whichever option opens the dialog box to allow you to select a printer.

- 3 From the list of printers, select **Nortel Fax**.
- 4 Click **OK** or **Print**, or whichever option sends the file to the printer you selected. The **Compose Fax** dialog box appears.




- 5 Click **Save As**.
- 6 Type a name for the file.
Note: If you chose to include a subject line, the information in that text box is displayed in the e-mail portion of the fax. The subject line is not displayed on a hard copy of the fax.
- 7 Browse to select a folder to save the file in.
- 8 Ensure the selected file format is TIFF-F (*.tif).
- 9 To save the file to the folder you specified, click **OK**.
- 10 Click **Exit**.

—End—

To compose and send a fax or text message

Step	Action
1	In your message list, click Compose . A new message page appears.
2	Address the message. For more information, see "Addressing messages" (page 29).
3	Add a fax file as an attachment as follows:

- a. Click **Attach Files**.
- b. In the **File to attach** box, click **Browse**, navigate to and select the file that you want to attach, and then click **Open**. Alternatively, you can type the path and file name in the **File to attach** box.



- c. To attach additional files, repeat the previous step.
 - d. Click **OK**. An icon representing each attached file appears beside the **Attach Files** button on the message.
- 4 If you want to include a message with the fax attachments, type the message.
 - 5 Click **Send**.

—End—

Calling the sender of a message

You can respond to a message with a telephone call instead of a recorded message. My CallPilot includes a Call Sender button that appears in both the message list and when you are in an open message. Clicking the Call Sender button calls the sender of the currently selected message, regardless of whether or not the message contains an audio attachment.

To use the Call Sender feature, ensure you have your telephone number configured in My CallPilot. To check, click the **My CallPilot Features** tab, and then click the **My CallPilot Preferences** item. In the **Environment Settings**, ensure your telephone number is entered in the **Number to call for telset playback (ie. your phone)** box.


If the Call Sender button does not appear, it could be due to the following:

- You are not viewing a message on the CallPilot server (for example, you are viewing a message on the e-mail tab that is linked to your e-mail inbox).
- The system administrator has not enabled this feature for your mailbox class.

To call the sender of a message

Step	Action
1	Open the message, or from the message list select the check box to the left of the message.
2	Click Call Sender .

One of the following dialog boxes appears, depending on whether or not you are using Internet Explorer and have the CallPilot Player installed.




- | | |
|---|---|
| 3 | Click either Call or Call Sender . |
| 4 | When your telephone rings, answer it and the sender's number is automatically called. |

—End—

Forwarding and replying to messages

You can forward a message, and compose an introduction to send with it. You can also compose a reply to the sender of a message, or to the sender and all recipients of a message.

To forward or reply to a message


Step	Action
1	In an open message, click Reply , Reply All , or Forward . 
2	On the new message page, compose a voice, fax, or text message.
3	Address forwarded messages the same way as a new message. Replies are addressed automatically.
4	Add attachments, set options, and change the subject line if required.
5	Click Send .
—End—	

Adding attachments to messages

Before sending a message, you can attach one or more voice, fax, or text files to it. Voice files can be either VBK or WAV format. My CallPilot automatically converts VBK files to WAV files when sending to systems that do not support VBK. Fax files must be TIF format. Text files must be TXT format.

To attach a file to a message

Step	Action
1	On a new message page, click Attach Files .
2	In the File to attach box, click Browse , navigate to and select the file that you want to attach, and then click Open . Alternatively, you can type the path and file name in the File to attach box.



- 3 To attach additional files, repeat the previous step.
- 4 Click **OK**. An icon representing each attached file appears beside the **Attach Files** button on the new message.
- 5 Continue to compose, address, and send the message as usual.

—End—

Setting message options

Before sending a message, you can set options for handling and delivery.

To set message options

Step	Action
1	<p>On a new message page, select Priority, Sensitivity, and read receipt options, as required.</p> <p>Options: Priority Normal Sensitivity Public <input type="checkbox"/> Notify me when message is read</p> <ul style="list-style-type: none"> For Priority, select Low, High, or leave the setting as Normal. For Sensitivity, select Private, or leave the setting as Public. <p>You cannot forward messages that are marked Private to other CallPilot addresses. However, be aware that when you send a message marked Private, your recipient can still forward the message to someone else, if the recipient does not have</p>

a CallPilot address. Also, recipients in non-CallPilot systems are not informed of Private settings. In your message, tell the recipient that the message is private.

- For **Notify me when message is read**, select the check box to request acknowledgment that your recipient opened the message.

2 Continue to compose, address, and send the message as usual.

—End—

Addressing messages

You can address a CallPilot message in two ways:

- You can select a name from the CallPilot Address Book that is maintained by your organization on the server. The CallPilot Address Book contains the addresses of the CallPilot users and shared distribution lists that you can use.
- You can manually enter addresses using the Enter a Special Address dialog box.

Accessing CallPilot addresses from other networked CallPilot servers

If your site has more than one CallPilot server, your CallPilot administrator can provide you access to additional CallPilot Address Books on networked servers. In this case, you can choose which CallPilot Address Book you want to search when addressing a message (see the Available Address Books list in the following illustration).

Alternatively, your CallPilot administrator can create a central directory of addresses drawn from multiple CallPilot servers. In this case, you do not have to choose the address book to search, but you automatically have access to an expanded list of CallPilot addresses to search when addressing a message.

If you do not need access to CallPilot addresses on other networked servers, you can configure your CallPilot Address Book to include only addresses from your local server using a check box on the My CallPilot Preferences page. For more information, see ["To change environment settings" \(page 54\)](#).

To address a message from the CallPilot Address Book

Step	Action
------	--------

- 1 In a new CallPilot message, click **To** (or **Address Book**).
The Select recipients from the Address Book dialog box appears.

- 2 If the **Available Address Books** list appears, you must choose which CallPilot server's Address Book or directory you want to search to address the message. The system administrator determines what you see in this list.
- 3 In the **Enter Last Name (or *)** box, do one of the following:
 - To look up a single address, type the recipient's last name (or just the first letter or first few letters), and then click **Find**.
 - To get a list of all entries in the Address Book, type an asterisk (*), and then click **Find**.
- 4 In the list of names, select the name of the recipient or distribution list, and then click **To**.
- 5 You can look up additional names as required. To add more names, select the name, and then click either **To**, **Cc**, or **Bcc**. (Bcc stands for blind carbon copy; the recipient gets a copy of the message, but the recipient's name is not visible to other recipients of the message.)

- 6 To return to the new CallPilot message, click **OK**.

—End—

To address a message in Special Addresses

Step	Action
------	--------

- | | |
|---|---|
| 1 | In a new CallPilot message, click Special Addresses .
The Enter a Special Address dialog box appears. |
|---|---|

- | | |
|---|--|
| 2 | Select an address format from the drop-down list (for example: Network mailbox or Personal Distribution List). Note that Personal Distribution List entries appear alphabetically sorted when doing an Address Book search. |
| 3 | Type the number and any other information required. Refer to the online Help for the correct addressing formats. |
| 4 | Click either To , Cc , or Bcc . |

—End—

Using the Message Waiting Indicator

My CallPilot includes a Message Waiting Indicator (MWI) that appears as a telephone handset icon in the lower-right corner of your screen, in the Windows taskbar or system tray. The Message Waiting Indicator notifies you if you have new messages and provides you with quick access to your inbox.

A red telephone handset icon indicates that you have new messages:



The appearance of the Message Waiting Indicator icon changes to give you additional information about your connection to the server as follows:



You are not logged on to CallPilot



You are logged on, but you have no new messages



There is a communication problem with the server

To download and install the Message Waiting Indicator

If you have desktop messaging installed on your workstation, or if you have already downloaded the stand-alone CallPilot Player, you should already see the Message Waiting Indicator in your taskbar. If you do not, you can download and install it as follows:

Step	Action
1	In My CallPilot, click the CallPilot Features tab.
2	Click the Downloads item.
3	Click CallPilot Player & MWI icon , and then follow the instructions to save and install the player and Message Waiting Indicator.
—End—	

To configure the Message Waiting Indicator

Use the CallPilot MWI Configuration dialog box to

- show or hide the Message Waiting Indicator
- enable and disable its pop-up balloon text
- control how long the balloon text stays on the screen

Step	Action
1	In the Windows taskbar, right-click the Message Waiting Indicator icon.
2	Click CallPilot MWI Configuration .
3	<p>If you want to be able to open My CallPilot by double-clicking the icon, ensure that the My CallPilot URL box contains the correct URL.</p> <p>Ask your CallPilot administrator for the correct URL. Typically, the URL appears in one of these formats:</p> <p><i>http://prefix.hostname.com/mycallpilot/</i></p> <p><i>http://IP address/mycallpilot/</i></p>
4	<p>To show or hide the icon, select or clear the Show MWI Icon on taskbar check box.</p> <p>Note: If you hide the icon and then decide you want to show it again, from the Windows Start menu, choose Programs > Nortel > CallPilot MWI Icon. It reappears in the taskbar.</p>
5	To enable or disable the balloon text, select or clear the Display pop-up balloon for x seconds check box. You can also change the number of seconds.
6	To save your changes, click OK .
—End—	

To use the Message Waiting Indicator

Here are some helpful tips for using the Message Waiting Indicator.

- To open your latest CallPilot message, double-click the Message Waiting Indicator icon.

Note: If this does not work, ensure that the **My CallPilot URL** box contains the correct URL in the **CallPilot MWI Configuration** dialog box. To open it, right-click the Message Waiting Indicator icon, and then click **CallPilot MWI Configuration**.


- To display your mailbox number, the address of the server, and the number of messages waiting in your inbox, move your pointer over the icon.
- Right-click the icon to display a shortcut menu with options to:

- open My CallPilot (if a URL for My CallPilot is defined in the configuration settings for the Message Waiting Indicator)
- configure the Message Waiting Indicator
- log on to or off from your CallPilot mailbox
- exit from the Message Waiting Indicator so it no longer appears

CallPilot Features tab

Click the CallPilot Features tab to change the settings for your CallPilot features and telephone options, and to set preferences for Web-based access.

The main CallPilot Features page displays only the features that are available for you to use. Click any item to open its settings page.



Working with greetings

Using My CallPilot, you can record and manage your voice greetings and personal verification.

If you use Internet Explorer on a Windows system, you can use the CallPilot Player to record and play greetings or personal verification from My CallPilot. Alternatively, you can import WAV files recorded on other audio devices for greetings and personal verification messages.

You can record external, internal, and temporary greetings. Callers from outside your organization hear your external greeting, and callers within your organization hear your internal greeting. If you do not record an internal greeting, all callers hear your external greeting. If you record a temporary greeting, it is played to all callers in place of your external and internal greetings until it expires or you delete it.

To access greetings

- Click the **CallPilot Features** tab, and then click the **Greetings** item.

The Greetings page appears.

My CallPilot Help | About | Logout

Mailbox: Elizabeth Spence (4445)

CallPilot Messages | **CallPilot Features** | Useful Information

00:00 [00:00] Save Greeting

Greetings

You can record external, internal and temporary greetings. Callers from outside your organization hear your external greeting, callers within your organization hear your internal greeting. If you do not record an internal greeting, all callers hear your external greeting.

Greetings	Edit	Import	Delete	Recorded
External Greeting				
Internal Greeting				
Temporary Greeting				

Expiry date

☒ No Expiry Date

☐ December 31 at 00:00

If you record a temporary greeting, it is played to all callers in place of your external and internal greetings until it expires or you delete it.

To record or change a greeting using your telephone

Ensure you have your telephone number configured in My CallPilot.

- To check, click the **My CallPilot Features** tab, and then click the **My CallPilot Preferences** item. In the **Environment Settings**, ensure your telephone number is entered in the **Number to call for telset playback (ie. your phone)** box.

Note: If you want to record greetings using the stand-alone CallPilot Player or another audio device instead of the telephone, see ["Importing a greeting recorded with a standalone audio device"](#) (page 36)

Step	Action
1	Click the CallPilot Features tab, and then click the Greetings item.
2	To start recording, click the Edit icon beside the greeting type.
3	When your telephone rings, answer it. At the tone, record your message into the handset.
4	When you finish speaking: <ul style="list-style-type: none"> • To end the recording, click the stop button. • To review the recording, click the play button.
5	When you are satisfied with the greeting, click Save Greeting .
6	When you are finished, click the disconnect icon or hang up the telephone.
7	If you recorded a temporary greeting and you want to revert back to your regular greeting by a certain date and time, under Expiry date , click the date option, and then select a date and time.
—End—	

Importing a greeting recorded with a stand-alone audio device

You can record and then import a new or changed greeting using the stand-alone CallPilot Player or any other audio device that supports WAV format.

Step	Action
1	Open your audio device and record a voice greeting or personal verification. To open the stand-alone CallPilot Player, from the Windows Start menu, choose Programs > Nortel > CallPilot Desktop Messaging > Audio Player.
2	Save the recording. For the CallPilot Player, save in VBK format. For other audio devices, save in WAV format.
3	Click the CallPilot Features tab, and then click the Greetings item.
4	Click the Import icon beside the greeting type.
5	Click Browse , select the audio file, and then click Open .
6	Click Save .

- 7 If you recorded a temporary greeting and you want to revert back to your regular greeting by a certain date and time, under **Expiry date**, click the date option, and then select a date and time.
- 8 Click **OK**.

—End—

To delete greetings

- | Step | Action |
|------|--|
| 1 | Click the CallPilot Features tab, and then click the Greetings item. |
| 2 | Click the Delete icon beside the greeting. |
| 3 | Click OK . |

—End—

Setting up message notification

CallPilot can notify you of new messages when you are away from the office. Your administrator defines whether these devices and services are available to you:

- Remote Text Notification to a wireless e-mail device. See [Appendix "Remote Text Notification for Microsoft Outlook and BlackBerry Devices" \(page 57\)](#).
- Remote Notification to a telephone or pager. This type of remote notification can be set up and turned on or off from your telephone as well. You can set up two time periods for notification, and choose whether you want to be notified of all messages or urgent messages only.

You can have the two types of notification turned on simultaneously.

To access message notification options

- Click the **CallPilot Features** tab, and then click the **Message Notification** item. The Message Notification page appears.

CallPilot Messages

CallPilot Features

Useful Information

Save

Cancel

Message Notification

You can receive notification of new CallPilot Messages at an email device, or a remote telephone or pager that you define. You can also specify which type of messages you wish to be called for, and define a calling schedule.

Remote Text Notification

Current Status: ☐ On ☒ Off

Device Service:

No Service

Your administrator defines the remote notification services supported by CallPilot.

E-mail address:

☐ This Device Supports Unicode

Notify for:

- ☒ All messages
- ☐ Urgent messages

CallPilot Messages
CallPilot Features
Useful Information

Remote Notification to telephone or pager

Current Status: ☐ On ☒ Off

Notification Device: Telephone Settings

Notification Number:

Notify for:

☒ All messages
☐ Urgent messages

Calling Schedule:

☐ Any time
☒ According to this schedule:

Days:

☒ Monday
☒ Tuesday
☒ Wednesday
☒ Thursday
☒ Friday
☐ Saturday
☐ Sunday

Time period during active day(s):

First time period:

From 09 : 00
To 17 : 00

Time zone: (GMT -04:00) Atlantic Time (Canada)
☐ Optional second time period:

From 17 : 00
To 09 : 00

Notification periods can cross midnight starting on your selected days. If the end time is earlier than the start time, it is assumed to be on the next day. For the entire day, use 00:00 to 00:00.

Save Cancel

Setting up message forwarding

You can forward your CallPilot messages to a CallPilot mailbox or to an external e-mail address. To do this you must create a message forwarding rule, which is a set of criteria defining which messages to forward and where to forward them.

When you enable a message forwarding rule, you can then access all incoming messages that meet the criteria from another location, such as an Internet mailbox or a Personal Digital Assistant (PDA). You can enable and disable message forwarding as required. Voice messages can be forwarded in the format in which they are received or converted to WAV.

In My CallPilot, you can set up your own message forwarding rule using the following procedures, or you can have the CallPilot administrator set it up for you. For security reasons, you must enable it yourself.

To set up message forwarding

Step	Action
1	Click the CallPilot Features tab, and then click the Message Forwarding Rule item.
2	Click Configure Rule . The Configure New Message Forwarding Rule page appears.

- 3 From the **Messages to forward** list, select the type of messages you want to forward.
- 4 From the **Forward to** options, select either **E-mail address** or **CallPilot address**. Note that each rule can include only one address.
- 5 Do one of the following:
 - If you chose **E-mail address**, type the address in the adjacent box.
Example: john.smith@acme.com
Note: You can also type an e-mail distribution list.
 - If you chose **CallPilot address**, you can either:
 - Click the **CallPilot** link to open the **Select Recipient** dialog box, and then select or type a CallPilot address or an Open VPIM address. Then click **OK**.

- Manually type a CallPilot mailbox or Open VPIM address. Note that CallPilot distribution lists, telephone numbers, and fax addresses are not accepted. Use the following address formats:

Local mailbox:

<local VPIM prefix><mailbox>@<local FQDN>

Remote mailbox:

<remote location VPIM prefix><mailbox>@<local FQDN>

Open VPIM:

VPIM=<VPIM shortcut><mailbox>/<remote FQDN>@<local FQDN>

- 6 If you want the original CallPilot message to appear as read (for example, not bold) in your mailbox under certain circumstances (see the next step), select the **Mark original message as read** check box.
- 7 If you checked the **Mark original message as read** check box, select one of the following options:
 - **Forwarded by this service:** As soon as a message is automatically forwarded, it appears as read in your CallPilot inbox.
 - **Opened by the recipient:** The message appears as read in your CallPilot inbox *only after* it is opened in the location to which it is forwarded. This option works only if the e-mail server to which the message is forwarded supports read receipt capability. This option is not supported if you forward messages to a CallPilot address.

For this option, you can also select **Then automatically delete original message**. This way, only the forwarded copy of the message is kept and you have only one copy to keep track of. Note that this option is not available if **Forwarded by this service** is selected, because there is no guarantee the message will ever be received by the remote e-mail server.
- 8 If you want to convert outgoing voice messages to WAV format, select the **WAV** option. You might want to do this if the CallPilot Player is not available to play VBK messages at the forwarding address.
- 9 To create this rule, click **Save**. Note that the rule is automatically enabled. To disable it until you are ready to use it, clear the **Enable** check box.

- 10 Click **OK**.

—End—

To enable or disable message forwarding

Step	Action
------	--------

- 1 Click the **CallPilot Features** tab, and then click the **Message Forwarding Rule** item. The Message Forwarding Rule page appears.

Message Forwarding Rule

CallPilot messages, which meet defined criteria, can be forwarded to a CallPilot mailbox or an external e-mail address. Contact your administrator for information about your organization's security policies regarding forwarding mail externally.

Enable	Recipient	Convert Voice to WAV	Forward	Delete
<input checked="" type="checkbox"/>	john.smith@acme.com	<input checked="" type="checkbox"/>	Voice Messages	

- 2 In the **Enable** column, select or clear the check box.
- 3 Click **OK**.

—End—

Managing personal distribution lists

A distribution list saves you time when you send messages to the same group of addresses. You can create up to 99 personal distribution lists, and enter a number and name to identify each list. Each personal distribution list can contain up to 200 entries.

A personal distribution list can contain any addresses to which you can send a message, except other personal distribution lists. An entry can be a mailbox number, shared distribution list number, network mailbox, open network mailbox, or telephone number.

You can create personal distribution lists in My CallPilot or on your telephone. These lists are stored for you in the CallPilot Address Book on the CallPilot server. You can access these lists from My CallPilot, Desktop Messaging, and your telephone.

To edit, delete, or create personal distribution lists

To edit or delete an existing list, select the list and click Edit or Delete. Make the changes, then click Save.

To create a personal distribution list, click Add New List. Type a number and name for the list. Add entries by selecting an address format from the drop-down list, then enter the information required. Refer to the online Help for the correct addressing formats, if required. Click Save.

Personal Distribution Lists
CallPilot messages addressed using distribution lists are sent to all people in the list. Distribution lists (up to 99) are addressed by their list number in outgoing messages.

Existing Personal Distribution Lists:

Number	Name	Number of Members	Edit	Delete
Number	Name	Number of Members	Edit	Delete

Personal Distribution Lists - Edit

Personal Distribution List Information

Number: 1 Name: My Team

Add/Remove Members

Add: Address Book
Local mailbox
Network mailbox
Find Name: Telephone number
Be: Open VPM
Name: Open AMIS
Shared Distribution List (SDL)
Beardsley Glenn[16129374265@cpi0008.us.r
Bedard Harry[16129374023@cpi0008.us.nort
Belcher Jamie[16129374780@cpi0008.us.nort
Bellew Laurie[16129374526@cpi0008.us.nort

Personal Distribution List Members:
3397240@ptord0hd.ca.nortel.com

Changing your CallPilot password

Your CallPilot password is the same password that you use to log on to CallPilot from the telephone. CallPilot requires that you change your password on a regular schedule set by your administrator.

CallPilot prevents you from using some passwords if they are too short or too simple, or if you have used the same one recently. Keep your mailbox secure by choosing passwords that are not easily discovered.

To change your password, type your old password, type your new password twice, then click Save.

Changing your telephone options

You can modify any of the telephone options described in the following procedures.

To access your telephone options

- Click the **CallPilot Features** tab, and then click the **Telephone Options** item.

To assign a custom operator number for callers

You can offer your callers the option of leaving a message or speaking to one of your assistants or colleagues. In your greeting, tell callers to press zero if they want to speak to this person in your absence. The custom operator number is the number your callers reach when they press zero.

Step	Action
1	In the Custom Operator Number box, type the number .
2	Click Save .

—End—

To set times and options for blocking messages from callers

You can temporarily prevent your callers from leaving messages in your mailbox. You can choose to transfer callers to your custom operator or disconnect them. As a courtesy to your callers while message blocking is turned on, record a temporary greeting that provides details of your absence and tells callers what to do. The message blocking option also prevents My CallPilot and Desktop Messaging users from sending messages to you.

Step	Action
1	In the Block callers from leaving messages list, specify when to block message reception: <ul style="list-style-type: none"> • Never: Allow callers to leave messages. • Always: Do not allow callers to leave messages. • Only when temporary greeting recorded: Do not allow callers to leave messages when the temporary greeting is recorded.
2	For Blocked callers will be played the greeting, then , choose one of the following options: <ul style="list-style-type: none"> • Transferred to custom operator: When message reception is blocked, play the mailbox greeting and then transfer the caller to the number specified in the Customer Operator Number box. • Disconnected: When message reception is blocked, play the mailbox greeting and then disconnect the call.
3	Click Save .
—End—	

To turn Auto Login on or off

When Auto Login is turned on, you do not have to enter your mailbox and password when you log on from a defined number. Your administrator defines secure numbers for Auto Login, such as your office or home telephone. When Auto Login is turned on, you access your mailbox by dialing the CallPilot access number or pressing the message key at one of your defined Auto Login numbers.

Step	Action
1	To enable Auto Login, select the Turn on Auto Login for allowed numbers check box.
2	Click Save .
3	Use your telephone to complete activation of Auto Logon. Log on to your mailbox from the telephone, and then enable Auto Logon by pressing 804.
—End—	

To hide your name and number in CallPilot Address Books

You can keep your personal information from being listed in any CallPilot Address Book or the address book of any desktop client, and ensure that your mailbox is not name dialable or name addressable from the telephone.

Even with this setting turned on, your name and address

- still appears in any messages you send
- still appears in any messages you receive and is therefore viewable by others on the distribution list for that message

Step	Action
1	Select the Hide my name and number in all CallPilot address books, including Name Dial check box.
2	Click Save .
—End—	

To select which directory numbers are associated to your Message Waiting Indicator

Message Waiting Indicator Directory Numbers (MWI DN) are assigned by the administrator. You cannot change the numbers; however, you can see these MWI DNs in your telephone options and identify which ones to associate to your Message Waiting Indicator.

Step	Action
1	In the Message Waiting Indicator at telephone section, select the check box beside each DN that you want associated with your Message Waiting Indicator.
2	Click Save .
—End—	

Setting up telephone access to e-mail

If you have a linked e-mail account set up, you can configure it for telephone access. You can check for new e-mail messages while logged in to CallPilot from your telephone. You can have the text content of any new e-mail messages read to you over the telephone. If you have not yet set up access to your e-mail accounts from CallPilot, see ["Setting up links to your e-mail accounts" \(page 48\)](#).

To set up an e-mail account for telephone access

Step	Action
------	--------

- 1 Click the **CallPilot Features** tab, and then click the **E-mail By Phone** item. The E-mail By Phone page appears, listing any mailbox links you currently have set up.

CallPilot Messages **CallPilot Features** **Useful Information**

E-mail By Phone

CallPilot allows you to listen to e-mail messages in one of your linked e-mail account folders when you log in using the telephone.
When you are logged in using the telephone, switch to your e-mail message list by pressing 8-9.

Mailbox link selection and voice configuration

Use voice of: Female - Mary

Select mailbox link for E-mail by Phone:

Enable	Enabled for My CallPilot	Mailbox Server	Folder	User Name	Edit	Delete
<input type="radio"/>		Exchange Domain Server	MyInbox	jbrowne		
<input checked="" type="radio"/>		Exchange Domain Server	INBOX	johnsmith		

Configure New Mailbox Link

OK

Note: If you need to set up or edit a mailbox link first, click **Configure New Mailbox Link**. See [To set up an e-mail link](#).

- 2 From the **Use voice of** list, select a female or male voice to read your e-mail.
- 3 In the **Enable** column, select one e-mail account for access by telephone.
- 4 Click **OK**.

You can now access your e-mail by logging on to your CallPilot messages using the telephone and then switching to your e-mail message list by pressing 8-9.

—End—

Changing fax printing options

If your CallPilot mailbox has fax messaging capability, you can receive a fax message in your mailbox and print the fax at a selected fax number. Set options for default fax number, Auto printing, and print cover page on the Fax Printing page.

To access fax printing options

- Click the **CallPilot Features** tab, and then click the **Fax Printing** item.

To change the default printer

You must set a default fax number. If you are not using Auto printing, a default fax number is the simplest way to print. The default number can be any fax number that CallPilot can dial, including any normally required prefixes.


To turn Auto printing on or off

When Auto printing is turned on, any faxes that arrive at your mailbox are automatically printed at a specified default fax number. A message that has been auto printed remains in your mailbox so that you can reprint the message or forward the message. Your printed faxes can be deleted automatically from your mailbox on a schedule set by your administrator.

Auto printing is the most convenient way to handle fax messages while you are in one location. If you are away from your office, you can turn Auto printing off and print your faxes at another fax number.

To turn fax separator page printing on or off

You can select whether to print a fax separator page when you print a fax message. A separator page identifies you and gives details of the print job, such as the number of pages. Separator pages are useful if you receive faxes without cover pages. If the sender of the fax includes a header page with the fax, the header page also prints.



The screenshot shows a web-based configuration window titled "Fax Printing". At the top right are "Save" and "Cancel" buttons. Below the title is a section labeled "Fax Messages Printing" with a light blue background. Inside this section, there is a label "Default fax number for printing:" followed by a text input field containing "338-7401". Below this are two checked checkboxes: "Auto Print new fax messages as received" and "Print a separator page with each printout".

Setting up links to your e-mail accounts

You can set up links in My CallPilot so that you can check your e-mail for new messages. You can also forward and reply to messages, and send new e-mails.

You can define up to five e-mail accounts. One of these accounts can be set up for access from your telephone. See ["Setting up telephone access to e-mail" \(page 46\)](#).

To set up a link to your e-mail account

My CallPilot supports various settings when configuring an external e-mail server. Some of these settings are configured in CallPilot Manager, while others are specified in My CallPilot. This way, My CallPilot can work correctly in situations where your corporate IMAP, SMTP and LDAP servers are on different hosts.

Consult your administrator if you are required to enter or change these settings and are uncertain of the appropriate entries.

Note: In the following procedure, the check boxes for **This server requires a secure connection** will appear automatically selected and dimmed if the CallPilot administrator has specified that only SSL connections can be used.

Step	Action
1	Click the CallPilot Features tab, and then click the Mailbox Links item.
2	Click Configure New Mailbox Link . The Configure New Mailbox Link page appears.

Configure New Mailbox Link

Mailbox link configuration

Mailbox server: Exchange Domain Server
Name to Display (on Tab): My e-mail
Mailbox Folder (e.g. INBOX): INBOX
E-mail address: jsmith@abcco.com
Mailbox user name: jsmith
Mailbox password:
Confirm password:
This server requires a secure connection: ☐

Outgoing mail server (SMTP)
Hide Details ☐

This server requires a username & password: ☐
Mailbox user name:
Mailbox password:
Confirm password:
This server requires a secure connection: ☐

Directory service (LDAP)
Hide Details ☐

This server requires a username & password: ☐
Mailbox user name:
Mailbox password:
Confirm password:
This server requires a secure connection: ☐

- 3 Select your e-mail server from the **Mailbox server** drop-down list. Your CallPilot administrator creates this list.
- 4 Type a name for this account to display on the tab.
- 5 Type the name of the folder to access for your e-mail messages, such as INBOX.
- 6 Type your e-mail address.
- 7 Type your mailbox user name (the user ID of your e-mail account).
- 8 Type the password for this e-mail account.
- 9 Retype the password for this e-mail account to verify it.
- 10 If the mail server for this e-mail account requires a secure connection, click **This server requires a secure connection**.
- 11 In the **Outgoing mail server (SMTP)** settings, complete the following steps if the SMTP server requires authentication:
 - a. Select the **This server requires a user name and password** check box.
 - b. Type your mailbox user name (the User ID of your e-mail account).
 - c. Type the password for this e-mail account.
 - d. Retype the password for this e-mail account to verify it.
- 12 In the **Directory service (LDAP)** section, complete the following steps if the LDAP server requires authentication:
 - a. Select the **This server requires a user name and password** check box.
 - b. Type your mailbox user name (the User ID of your e-mail account).
 - c. Type the password for this e-mail account.
 - d. Type the password again to verify it.
- 13 Click **Save**.
- 14 On the **Mailbox Links** page, click **OK**. A new tab appears in My CallPilot with a link to the e-mail account you just configured.

—End—

These settings allow My CallPilot to be configured easily to work in nearly any corporate e-mail environment.


Note: To log on anonymously, clear **This server requires a user name and password**, for both SMTP and IMAP. Note that some servers require authentication and do not allow logging on anonymously.

Searching external e-mail address books (LDAP databases)

You might have access to an external address book if there is one defined for your e-mail server and it is configured by your administrator in CallPilot Manager. In the preceding procedure, completing the fields in the Directory Service (LDAP) section allows you to search external LDAP databases if the LDAP server requires authentication. This means you can search the external address book when composing a new external e-mail server message, just as you do when composing a CallPilot message. Note that you do not have the ability to specify the port numbers; these are defined by the administrator in CallPilot Manager.

Note: The administrator must enter the correct search base, host/IP and port number for the external LDAP server in CallPilot Manager when the external e-mail server is defined.

The following shows an example of an external e-mail server address book in My CallPilot:



When you address a message, the address book that appears depends on the inbox you are working from. For example, when you compose a new CallPilot message, the address book displays addresses only from the CallPilot server. When you compose a new Exchange message, the address book displays addresses only from the Exchange server, and so on.

Distribution lists may appear in the results.

Using your linked e-mail accounts

When you have completed configuring your linked e-mail accounts, you can check your e-mail messages. You can also forward and reply to messages, and send new e-mails.

You can also set up access to a second CallPilot mailbox, which can be on another server. For setup details, refer to the online Help.

For each linked e-mail account, a tab appears in your My CallPilot session. Your linked e-mail accounts look similar to your message list on the CallPilot Messages tab, and they work in a similar way. Here is an example:



To open a message

To open an e-mail message in My CallPilot, click the icon in the Attachments column beside the message, or click any underlined part of the message line.

To delete a message

To mark an e-mail message for deletion, select the message and click **Delete**. To ensure that deleted messages are permanently deleted, open the My CallPilot Preferences page, and in Environment Settings, check the Remove Deletable items on logout check box.

To compose and send a new message

To compose a new e-mail message, click Compose, type the message, and send the message the same way as a CallPilot message. The Address Book is not available.

To forward and reply to messages

You can forward and reply to e-mails in the same way as CallPilot messages. You might have access to an external address book if there is one defined for your e-mail server and it is configured by your administrator in CallPilot Manager.

Setting messaging preferences

You can set preferences for your message list displays and behavior, options for message editing, and your default audio format for voice messaging.

To access messaging preferences

- Click the **CallPilot Features** tab, and then click the **My CallPilot Preferences** item.

To change message list columns

You can change the columns in your message list. The Attachments option must be in the Displayed Columns list to see the embedded player (Windows only) in your message list.

CallPilot Messages CallPilot Features Useful Information

Save Cancel

My CallPilot Preferences

Message List

Available Columns

Displayed Columns

Check Box
Urgent
Private
Message Icon
Attachments

Move Up
Move Down

(Audio Player appears with the Attachments column.)

Number of messages per page: 25

If you are using a slow connection, you may wish to limit the number of messages displayed at once.

Signature Settings

Enter your signature details here: (Note: The maximum size of signature text is 255 characters.)

☐ Automatically add signature to out going message

To add a signature

Type or paste your signature and other information, and then select the check box if you want this signature added automatically to outgoing text messages.

Signature Settings

Enter your signature details here: (Note: The maximum size of signature text is 255 characters.)

John Smith
Manager - Information Services
1-800-555-1212

☐ Automatically add signature to out going message

To change environment settings

Change any of these My CallPilot settings to your preferences.

Environment Settings

☐ Show BCC while composing
 ☐ Confirm when messages are sent

☒ Show Priority, Sensitivity, Read Msg Notification
 ☒ Confirm deletions

☐ Notifv me when message is read
 ☒ Remove Deletable items on logout

☐ Use address book only from local CallPilot server

Check for new messages every: 10 minutes

Automatically logout after: 20 minutes

Audio: Standard (WAV)

Number to call for telset playback (ie. your phone): 7403

Note: The Remove Deletable items on logout check box applies to both CallPilot and regular e-mail messages, as well as messages you access when using E-mail-by-Phone.

Choosing a home page for My CallPilot

Choose the page that you want to display automatically when you log on to My CallPilot.

SaveCancel

My CallPilot Home Page
 Choose your default home page.

Available CallPilot pages:

☐ CallPilot Mailbox
☐ CallPilot Features
☒ Useful Information

Useful Information tab

Click the Useful Information tab to:

- View status and details about your mailbox.

- View online user guides.
- Print online user guide files on your laser printer.

CallPilot Messages
CallPilot Features
Useful Information

Your Mailbox Status

1. Your mailbox can store approximately **15** minutes of audio.
2. Voice messages are deleted **7** days after listening to them.
3. Read faxes are deleted after **7** days.
4. When your mailbox is full, your call answering is **not blocked**.
5. Messages that you send **are not saved** in your mailbox.
6. The maximum length of an outgoing message is **10** minutes.
7. An incoming message can be no longer than **5** minutes.
8. Your password was last changed **thursday 02 november 2006 at 13:24:57**.
9. Last logon to this mailbox was **friday 22 december 2006 at 01:33:32**.
10. Number of failed logon attempts **0**.

CallPilot Access Numbers

1. Voice Messaging:	4300
2. Express Voice Messaging:	n/a
3. Speech Activated Messaging:	n/a
4. Name Dialing:	(Not Available)
5. Default Fax Number:	n/a
6. Fax Messaging:	n/a
7. Express Fax Messaging:	n/a
8. Dial Prefix:	9
9. Area Code:	506
10. Exchange:	n/a
11. ESN Access Code:	6
12. ESN Exchange:	(Not Available)

Need More Help?

No CallPilot support information has been defined.

CallPilot User Documentation

[PDF User Guides and Reference Cards](#)

Transcribing voice forms

You can use My CallPilot to transcribe voice forms, if your system administrator has granted you this capability. If so, your My CallPilot session includes a tab called Voice Forms Transcription.

A voice form is an electronic equivalent of a paper form or questionnaire. Voice forms can be used for services such as credit card applications, registration forms, and customer complaints. Using My CallPilot, you can retrieve and play back the responses left by callers to a voice form.

For detailed procedures for using My CallPilot to transcribe voice forms, see *Voice Forms Transcriber User Guide* (NN44200-110), or refer to the My CallPilot online Help.

Protecting the security of your mailbox

Because My CallPilot is a Web-based product, it is important to take precautions to protect the security of your mailbox.

- If your administrator has enabled SSL encryption, you can use the Secure Login feature for greater security. See ["To log in using secure login" \(page 15\)](#).
- When you finish using My CallPilot, make sure that you log out. If you go to a Web site outside of My CallPilot without logging out, you remain logged in until your My CallPilot session times out. This can make your CallPilot information vulnerable to hackers. If you want to visit a Web site without exiting My CallPilot, use a separate browser window to view the other site.
- You can set CallPilot to log out automatically after a short time, such as 5 or 10 minutes. See ["Setting messaging preferences" \(page 53\)](#).
- If you use a public or shared workstation, avoid using the Remember Password option when you log on to My CallPilot. If this option is selected, others can access your CallPilot mailbox.
- If you use a public or shared workstation, empty the browser cache after a CallPilot session. For information about your browser cache, see your browser online Help.

Appendix A

Remote Text Notification for Microsoft Outlook and BlackBerry Devices

Remote text notification can be configured to send a message to your SMTP e-mail account when a new voice, fax, or text message arrives in your CallPilot mailbox. You can set up notification to any e-mail server that supports SMTP. These include most e-mail accounts, wireless handheld organizers, mobile phones, or PDAs like the Research In Motion BlackBerry.

To set up My CallPilot for remote telephone or pager notification, see ["Setting up message notification" \(page 37\)](#). If you want to forward the actual messages to a PDA that supports e-mail, you or your administrator can configure a message forwarding rule to do this. See ["Setting up message forwarding" \(page 39\)](#).

This section describes how to set up remote text notification for Microsoft Outlook and BlackBerry devices. Any device or portal with a service provider that supports SMTP can receive e-mail notification messages. If you plan to use another type of device to receive remote text notification, ask your CallPilot administrator about any additional setup that is required for your device.

To receive notification messages on a Research In Motion (RIM) BlackBerry Internet Edition device, you must configure Microsoft Outlook and BlackBerry Desktop Manager (version 2 or later) to forward CallPilot notification messages to your BlackBerry device.

If you use a BlackBerry Enterprise Edition device, your administrator can set up notification message forwarding for you on the e-mail server or configure BlackBerry Desktop Manager to redirect CallPilot notification messages.

Note: If you set up My CallPilot to send CallPilot notification to your Outlook Inbox, and set up BlackBerry Desktop Manager to send all incoming messages to your BlackBerry device, your CallPilot notification

messages appear in your list of e-mails on your BlackBerry device with no additional configuration required.

Notification message format

An e-mail notification message can show the:

- type of message
- name of the person who left the message, if available
- telephone number, if available

For example, John Smith calls from extension 1234 and leaves a voice message for Andrew Jones. An e-mail message is sent to Andrew Jones with the following text:

You have a voice message from John Smith [1234]

Microsoft Outlook forwards this e-mail message to Andrew's BlackBerry device. The message appears with the subject CallPilot Notification. When Andrew receives the message, he can decide whether to retrieve the message from CallPilot or to call John immediately, using a telephone.

Getting started with remote text notification

Requirements

- You need a BlackBerry device. Ensure that e-mail service on your BlackBerry device is working.
- Microsoft Outlook must be installed. Currently, BlackBerry Desktop Manager works only with Microsoft Outlook. Consult your BlackBerry documentation for information about other e-mail clients.
- BlackBerry Desktop Manager 2 or later must be installed and running on your computer.
- Remote text notification capability must be enabled and set up for your mailbox by your CallPilot administrator.
- Remote text notification must be configured and enabled in My CallPilot. For more information, see "[Setting up message notification](#)" (page 37).

Configuration steps

Complete the following steps to effectively manage e-mail notification messages.

Step	Reference
Create a holding folder for your e-mail notification messages so that they are stored separately from your other messages.	"Creating a notification holding folder" (page 59)
If you want to forward all messages in your Outlook inbox to your BlackBerry device, you can skip this step.	
Configure BlackBerry Desktop Manager to forward messages to your BlackBerry device.	"Configuring BlackBerry Desktop Manager" (page 62)
If desired, configure Outlook to delete old CallPilot notification messages automatically from the holding folder.	"Automatically removing notification messages" (page 63)
Alternatively, you can manually delete notification messages from the holding folder.	

Creating a notification holding folder


You can create a holding folder for your CallPilot e-mail notification messages so that they are stored separately from your other messages. To store messages in the folder, follow these steps:

Step	Action
1	Create an Outlook folder for the notification messages.
2	Configure Outlook to route CallPilot notification e-mail messages to the folder using the Rules Wizard.
—End—	

To create a notification folder

Step	Action
1	Start Outlook.
2	In the Folder List, select Outlook Today .
3	From the File menu, choose New > Folder . The Create New Folder dialog box appears.


- 4 In the Name box, type CallPilot Notification, and then click **OK**. The CallPilot Notification folder appears in the Folder List.



—End—


To route notification messages to the holding folder

Step	Action
1	Choose Tools > Rules Wizard . The Rules Wizard dialog box appears.
2	Click New . The first panel of the Rules Wizard appears.
3	In the list of rule types, select Check messages when they arrive , and then click Next .
4	In the list of rule conditions, check With Specific words in the subject box.
5	In the Rule description box, click Specific Words . The Search Text dialog box appears.




- 6 In the Add new box, type **CallPilot Notification**.

- 7 Click **Add**. The text "CallPilot Notification" is added to the Search list box.
- 8 Click **OK**. The search text "CallPilot Notification" appears in the rule description.



- 9 Click **Next**.
- 10 In the list of actions, check the **move it to the specified folder** box.
- 11 In the Rule description box, click **Specified**. A list of Outlook folders appears.
- 12 In the folder list, choose **CallPilot Notification**, and then click **OK**. The folder name appears in the rule description.
- 13 Click **Finish**. The finished rule is shown in the following illustration:



- 14 Click **OK** to close the Rules Wizard.

—End—


Configuring BlackBerry Desktop Manager

This section explains how to configure BlackBerry Desktop Manager to redirect your e-mail notification messages.

If you did not create a holding folder for notification messages, and if you already configured BlackBerry Desktop Manager to forward messages in your Outlook inbox, you can skip this section.

To configure e-mail redirection

Step	Action
1	From the Windows Start menu, choose Programs > BlackBerry > Desktop Manager. BlackBerry Desktop Manager appears.
2	In the application list, double-click Redirector Settings. The Redirector Settings dialog box appears.
3	Click the Advanced tab.



- 4 In the Folder redirection section, choose Selected folders.
- 5 Click Choose Folders... .The Choose Folders dialog box appears.
- 6 Select the folders where you receive messages that you want to redirect to your BlackBerry device.
 - To redirect messages in your holding folder, select the CallPilot Notification folder.
 - To redirect all messages in your Outlook inbox, select the Inbox folder.

- 7 Click Save to save your folder selection.
- 8 Click OK to save your redirection options.
- 9 Exit BlackBerry Desktop Manager.

—End—

Automatically removing notification messages

This section explains how to configure Outlook to remove messages automatically from the CallPilot Notifications holding folder using the AutoArchive feature. If you do not want Outlook to delete notification messages automatically, you can manually delete them from the folder.

ATTENTION

If you currently do not use AutoArchive, ensure that you become familiar with this feature before you activate it. You can have existing folders with AutoArchive settings that have never been activated. If you activate AutoArchive to delete messages automatically from the CallPilot Notifications folder, you might find that messages in other folders are being archived as well.

If you are unsure about what to do, check with your local Microsoft Outlook support group.

Step Action

You must perform two steps to configure automatic deletion of notification messages:


- 1 Set up AutoArchive to delete messages from the CallPilot Notifications folder.
- 2 Activate the AutoArchive feature.

—End—

To set up deletion of notification messages

Step Action

- 1 In the Outlook Folder List, right-click the **CallPilot Notifications** folder, and then choose **Properties**. The CallPilot Notification Properties dialog box appears.
- 2 Click the **AutoArchive** tab.




- 3 Select the **Clean out items older than** check box.
- 4 Set the time to 1 day.
- 5 Select **Permanently delete old items**.
- 6 Click **OK**.

—End—

To activate AutoArchive

Step	Action
1	In Outlook, choose Tools > Options .
2	Click the Other tab.
3	Click AutoArchive . The AutoArchive dialog box appears.



- 4 Check the AutoArchive every... box and set the frequency to 1 day.
- 5 Click **OK** to close the dialog box.

- 6 Click **OK** to close the Options dialog box.

—End—

Nortel CallPilot

Desktop Messaging User Guide for My CallPilot

Copyright © 2007, Nortel Networks
All Rights Reserved.

Publication: NN44200-109
Document status: Standard
Document version: 01.01
Document date: 26 February 2007

To provide feedback or to report a problem in this document, go to <http://www.nortel.com/documentfeedback>

Sourced in Canada

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

